

## **Sicherheitshinweise, Pflege und Wartung**

- Bewahren Sie das Gerät vor extrem hohen und niedrigen Temperaturen, vor direkter Sonneneinstrahlung sowie Wasser, Feuchtigkeit und Flüssigkeiten
- Verwenden Sie keine scheuernden Reinigungsmittel oder scharfen Gegenstände. Versuchen Sie nicht, das Gerät selbst zu reparieren oder auseinanderzubauen. Halten Sie das Gerät frei von Staub, Flusen etc.
- Außerhalb der Reichweite von Kindern aufbewahren.
- Werfen Sie das Gerät nicht ins Feuer (Explosionsgefahr)
- Versuchen Sie nicht, das Gerät zu zerlegen.
- Reparaturen an elektrischen Geräten sollten nur von einem qualifizierten Elektriker durchgeführt werden.
- Verwenden Sie das Gerät NICHT, wenn es feucht ist, um die Gefahr eines Stromschlags, Explosionen oder Selbstverletzungen zu vermeiden.

NICHT verwenden, wenn das Gerät fallen gelassen oder beschädigt wurde

- Bei Rauchentwicklung, ungewöhnlichen Geräuschen oder starker Hitzeentwicklung bringen Sie die Powerbank an einen sicheren Ort im Freien. Im Falle eines Brandes löschen und kühlen Sie mit ausreichend Wasser und alarmieren im Zweifelsfall die Feuerwehr.

Lithium-Ionen-Akkus können auch nach dem Löschen noch für längere Zeit rückzünden. Lagern Sie den gelöschten Akku / das gelöschte Gerät aus diesem Grund auch nach dem Ablöschen in einem Wasserbecken oder einem anderen geeigneten Behältnis.

- Überladen Sie die Powerbank nicht. Trennen Sie sie vom Ladegerät, sobald sie vollständig aufgeladen ist.
- Wenn anwendbar: „Bewahren Sie Plastiktüten, Folien, Styropor und andere Verpackungsmaterialien außerhalb der Reichweite von Kindern auf, da diese zum Ersticken führen können.
- Stellen Sie sicher, dass Ihr Gerät Kompatibel mit der Powerbank ist.

Platzieren Sie keine metallischen Gegenstände zwischen Ihrem Gerät und der kabellosen Ladefläche der Powerbank.

## **Safety Instructions, care and maintenance**

- Keep the unit away from extremely high and low temperatures, out of direct sunlight and away from water, humidity and any liquids

- Do not use abrasive cleaning agents or sharp objects. Do not attempt to repair or dismantle the appliance yourself. Keep the appliance free from dust, fluff, etc.
- Keep the unit free of dust, lint, etc.
- Keep out of reach of children
- Do not throw the unit into fire (risk of explosion)
- Do not attempt to disassemble device
- Repairs to electrical equipment should only be performed by a qualified electrician
- DO NOT use if the unit is moist in order to avoid danger of electric shock, explosions or injuring yourself
- DO NOT use if the unit has been dropped or damaged

In the event of smoke, unusual noises or excessive heat, move the power bank to a safe place outdoors. In the event of a fire, extinguish and cool with sufficient water and, if in doubt, alert the fire brigade.

Lithium-ion batteries can continue to reignite for a long time after extinguishing. For this reason, store the extinguished battery/device in a basin of water or other suitable container even after extinguishing.

- Do not overcharge the power bank. Disconnect it from the charger, as soon as it is fully charged.
- If applicable: 'Keep plastic bags, foils, polystyrene and other and other packaging materials out of the reach of children children, as these can cause suffocation.
- Ensure that your device is compatible with the power bank.

Do not place any metal objects between your device and the wireless charging surface of the power bank.